

取扱説明書

JP

使用前


初めてお使いになる際は必ずフル充電を行ってからご使用ください。充電時間は約1時間で、フル充電するとLEDランプが点灯します。

本製品を使用する際には、乳首や性器などのピアスやアクセサリーを取り外して、本製品を洗浄・消毒してからご使用ください。ローションを使用する場合は、水溶性ローションで製品とプライベートパーツをよく潤滑してください。

製品仕様

商品名: Abe 黒いローズ	定格電圧: 3.7V
型番: BJ558A	定格電流: 300mA
材質: シリコン、ABS樹脂	充電時間: 1時間
サイズ: 100*64*42mm(本体)、65*37*20mm(リモコン)	稼働時間: 50分
重量: 92g±5g(本体、15g(リモコン))	振動モード: 10種類(頭・脚)+10種類(足指)
電池種類: リチウムポリマー電池	防水等級: IPX6
電池容量: 240mAh	

ボタンについて



振動ボタン(頭側)
振動ボタン(足指)

一時停止ボタン
振動ボタン(足指)

マグネット充電ポート

使用方法

本体操作について

「▲」を1.5秒間長押しすると、頭側の振動モードがオン/オフします。

「▲」を短押しすると、10種類の振動パターンが切り替わります。

「▼」を1.5秒間長押しすると、足側の振動モードがオン/オフします。

「▼」を短押しすると、10種類の振動パターンが切り替わります。

本体操作について

「▲」または「▼」ボタンを1.5秒長押しすると、本体が待機状態になります。

「○」を短押しすると、「▲」ボタンランプが点滅し、頭側の10種類の振動パターンが切り替わります。

「○」を短押しすると、「▼」ボタンランプが点滅し、足側の10種類の振動パターンが切り替わります。

「○」を電源ボタンを短押しすると、2つのボタンとも点灯し、振動が一時的に停止します。

「○」/「○」を短押しすると、振動が再開します。「○」電源ボタンを1.5秒間長押しすると、本体の電源がオフします。

LED表示状態

動作中	LED点灯
電池残量低下	LED点滅
充電中	LED点滅
充電完了	LED点灯

ご使用上の注意事項

この製品をご使用になる前に、必ずこの取扱説明書を最後までよくお読みいただき、使用上の注意事項、本製品の機能や使用方法などを十分に理解して、正しく安全にご使用いただくようお願いいたします。また、この取扱説明書は大切に保管していただき、今後の参照のためお手元に置いておくことをおすすめします。●使用する前に製品をきれいに清潔にし、水溶性ローションを合わせて使用してください。●長時間に使用しない場合はよく洗浄し、専用の収納袋に収めてから、直射日光のある場所や高温、多湿になる場所を避けて保管してください。

充電について

●充電する際は必ず通常充電仕様のACアダプターと付属の充電ケーブルをご利用ください。急速充電仕様のものをご利用する場合は、製品の内部電池が劣化したり、フル充電できなったりする恐れがあります。●充電時は接続部分が濡れないようにご注意ください。

ださい。●充電時間は12時間を超えないように注意してください。また充電する際は必ず目を離さず、注意監視してください。●充電しなからでのご利用はお止めください。

メンテナンス

●本製品は防水レベルIPX6に達しておりますが、水中での使用はなるべく避け下さい。放水すると故障する恐れがあります。●洗浄後は水をよく拭き取ってから、直射日光の当たらない所で保管してください。●初めてご利用するときや長期間ご使用しなかった時は必ず一度満充電にしてからご利用ください。

警告

●アダルトグッズのため、幼児の手の届かないところに保管してください。●本製品を使用中に皮膚アレルギーや不快感を感じた場合は、直ちに使用を中止し、必要に応じて医師の診察を受けてください。●故障が見つかったり、異常な動作を感じたら、直ちにご使用を中止し、電源を切ってください。

廃棄物処理

●本製品はリチウムポリマー電池を内蔵しております。家庭ごみとして、処理しないでください。廃棄する場合は、電池を取り出してから各自自治体の処理方法に従ってください。

EN

Before Use


Please fully charge our product before the first use. The charging time is about 1 hour, after it's fully charged, the LED light will stay on.

Please remove piercings or jewelry in the nipple, genital, and other areas before use. Be sure to clean and disinfect the product before use. If you want to use a lubricant please adequately lubricate the product and your private parts with a water-based lubricant.

Product Specification

Product Name: Abe Black Rose	Rated Voltage: 3.7V
Product No.: BJ558A	Rated Current: 300mA
Material: Silicone, ABS	Charging Time: 1H
Size: 100*64*42mm (Cock Ring), 65*37*20mm (Remote)	Working Time: 50Min
Weight: 92g±5g (Cock Ring), 15g (Remote)	Vibration Mode: 10(Head)+10(Foot)
Battery Type: Polymer lithium battery	Waterproof Rating: IPX6
Battery Capacity: 240mAh	

Button Display



Vibration Button (Head)
Vibration Button (Foot)

Vibration Button (Head)
Pause Button
Vibration Button (Foot)

Magentic Charging Port

How to Use

Vibration Mode

Press the button "▲" for 1.5s to turn on/off the vibration mode of the head.

Click the button "▲" to switch 10 different vibration modes.

Press the button "▼" for 1.5s to turn on/off the vibration mode of the foot.

Click the button "▼" to switch 10 different vibration modes.

Remote Controller Mode

Press the button "▲" or "▼" to turn on the vibration mode of the head or the foot.

Click the button "○" to switch 10 different vibration modes of the head.

Click the button "○" to switch 10 different vibration modes of the foot.

Click the button "○" to pause both parts while two LED lights are on.

Click the button "○" or "○" to resume. Press the button "○" for 1.5s to turn off the power.

LED Display

Working	LED remains on
Low battery	LED flashes
Charging	LED flashes
Fully Charged	LED remains on

Charging

Please use the charger provided by the official manufacturer. The cable must dock with magnetic contacts on the toy's metal contact points intended for this purpose. If the charging cables does not adhere to the contact points by itself, connect it to the electrical supply and wait a moment. The magnetic effect will thus be reactivated, and the contacts will connect automatically. Please keep the charging dock dry to avoid affecting the magnetic effect and the charging time should not exceed 12 hours.

Maintenance

Please use the charger provided by the official manufacturer. The cable must dock with magnetic contacts on the toy's metal contact points intended for this purpose. If the charging cable does not adhere to the contact points by itself, connect it to the electrical supply and wait a moment. The magnetic effect will thus be reactivated, and the contacts will connect automatically.

will connect automatically. Please keep the charging dock dry to avoid affecting the magnetic effect and the charging time should not exceed 12 hours.

Warning

If you have skin allergies or discomfort while using this product, please stop immediately and go to the hospital if necessary. Please read the user manual carefully and use the product safely according to the instructions.

Waste Disposal

Please legally dispose of used batteries. Never throw away electronic devices or batteries in household waste. Please send it to the appropriate waste electrical or electronic recycling station to ensure environmentally friendly disposal.

TW

使用前

在第一次使用前，請將產品充滿電。充電時間約為1小時，充滿電後LED長亮。

使用前請將乳頭、生殖器和其他部位的穿孔或首飾取下並對產品進行清潔和消毒。如使用潤滑液，請用水溶性潤滑液充分潤滑產品和您的私處。

產品規格

產品名稱: Abe 黑玫瑰	額定電壓: 3.7V
產品型號: BJ558A	額定電流: 300mA
材質: 矽膠, ABS	充電時間: 1小時
尺寸: 100*64*42mm(本體), 65*37*20mm(遙控器)	使用時間: 50分鐘
重量: 92g±5g(本體, 15g(遙控器))	振動模式: 10種類(頭部)+10種類(足部)
電池類型: 充電式聚合物電池	防水等級: IPX6
電池容量: 240mAh	

按鍵解析



頭部振動鍵
足部振動鍵

頭部振動鍵
暫停鍵
足部振動鍵

磁吸充電孔

如何使用

振動模式

長按「▲」鍵1.5秒，開啟/關閉頭部振動模式。

點選「○」鍵循環切換10種振動模式。

長按「▼」鍵1.5秒，開啟/關閉足部振動模式。

點選「○」鍵循環切換10種振動模式。

遠端控制模式

長按「▲」鍵或「▼」鍵1.5秒，開啟/關閉頭部或足部的振動模式。

點選「○」鍵循環切換頭部的10種振動模式。

點選「○」鍵循環切換足部的10種振動模式。

點選「○」暫停所有振動同時兩燈亮起。

點選「○」/「○」恢復振動。長按「○」鍵1.5秒，關閉電源。

LED顯示狀態

工作中	LED長亮
低電量	LED閃爍
充電中	LED閃爍
充滿電	LED長亮

使用注意事項

充電

請使用官方廠商提供的充電器。充電線必須與玩具專用金屬接觸點上的磁性接點對接。如果充電線沒有黏在接觸點上，請將其連接到電源插頭等物件。這將導致磁場重新激活，觸點自動連接。請保持充電線乾燥，以免影響磁性效應。充電時間不要超過12小時。

維護

本產品符合IPX6國際防水標準，可防止各個角度低壓水流。請勿在水下使用本產品。

為獲得更好的體驗，請使用水溶性潤滑液。每次使用前後請清潔並在清洗後完全乾燥。請將其保存在安全乾燥的地方，避免陽光直射。

警告

如果您在使用本產品時出現皮膚過敏或任何不適，請立即停止使用，必要時及時就醫。使用前請仔細閱讀說明書，並按照說明書安全使用產品。

廢物處理

請依法處理用過的電池。切勿將電子設備或電池丟棄在生活垃圾中。請將其送至相應的廢舊電器或電子產品回收站，以確保環保處理。

BJ558A 说明书
成品尺寸:100×70mm
材质:80g书纸 四色印刷 骑马钉

